


AIR HOPPER GUN



PARTS NO.	DESCRIPTION	QUANTITY	PARTS	DESCRIPTION	QUANTITY
01	Air in Let	1	09	Cup	1
02	Gun Body	1	10	Clamp	1
03	Liquid Tube	1	11	O-ring	1
04	Spring	1	12	Fluid Nozzle	1
05	Adjusting Screw	1	13	Air Cap	1
06	Trigger Pin	1	14	Seal Screw	1
07	Trigger	1	15	Lock	1
08	Stopper	1			